

MFC-2065

INSTRUCTION MANUAL

+Receiver + GYRO wiring version V1.0

- 01. Independent power management system 25, 7.4v input voltage design, 20A maximum current output, can meet most market demand.
- 02. Support the electromagnetic brake function to reduce the aircraft landing distance.
- 03. Support LED light control system, 4 groups are always on, 3 groups are slow

PRODUCT FEATURES

flashing mode.

- 04. Flight path compensation system is supported. Elevator compensation of throttle and flap can be set according to aircraft characteristics.
- 05. Support dual s-ubs bus function and double receiving function.
 06. The back outlet design is adopted, the wiring is arranged below the installation position, and the receiver and power line are connected on the side, so the installation is convenient, simple and beautiful.
- 07. There are five gears in the hybrid control system, the first gear is 3% compensation, the second gear is 6% compensation, and the compensation amount of each gear is added by 3%.
- 08. In normal operation, the LED indicator light is slow flashing, and when adjusting the mixed control, the LED indicator light is fast flashing.
- 09. Once the adjustment button is pressed, the LED indicator will flash once to turn off the compensation, two times to turn on the first gear compensation, three times to turn on the second gear compensation, and so on. The mixed control gear can be adjusted circularly. 10. Adjust the throttle compensation: the flap signal line cannot be connected. The receiver line must be in PWM connection mode and adjusted according to mixed control.
- 11. Adjust flap compensation: the receiver must be connected with flap signal line. In PWM connection mode, press mixed control adjustment.
- 12. Positive and negative adjustment of flap compensation actuator: press the adjustment button to power on the control box, and release the button after 5 seconds.
- 13. Positive and negative adjustment of throttle compensation actuator: if the flap signal line cannot be connected, press and hold the adjustment button to power on the control box, and release the button after 5 seconds.

SYSTEM CONNECTION DIAGRAM REFERENCE (MFC-2065 + GYROSCOPE + PWM RECEIVER)

